

ReAxle Fitting Instructions

Tools required

- 5mm allen key or 17mm spanner
- Synthetic bike grease
- 24mm or 15/16 inch socket
- Torque wrench for above socket (Torque 60 N·m / 44 ft·lbf)

Steps

- 1 Remove bike from Neo turbo trainer
- 2 Remove non-drive side axle adaptor using 5mm allen key or 17mm spanner depending on version
- 3 Apply grease to ReAxle thread and flange face as shown
- 4 Screw ReAxle into Neo turbo trainer and torque to 60 N·m / 44 ft·lbf
- 5 Replace bike on Neo turbo trainer and you are ready to ride!



Note – If you do not own and are unable to borrow a torque wrench you may be able to take your Neo to your local bike shop or vehicle repair shop and get them to torque your ReAxle.